



Pos.	Code NR	Description
1	4616.100	Butterfly Nut
2	4616.114	Reflector
3	4616.103	Double-Headed Stud
4	4616.113	Protect Ring For Housing Lid
5	4616.112	Protect Ring For Tank Housing
6	S/R	Tank Housing
7	S/R	Main Pole
8	S/R	Support Leg
9	S/R	Base
10	S/R	Small Mesh
11	4616.111	Pipe
12	4616.119	Wheels
13	4616.105	Flame Screen
14	S/R	Top Fire Plate
15	S/R	Protect Mesh
16	S/R	Bottom Fire Plate
17	S/R	Gas Throat Tube
18	S/R	Connect Panel
19	4616.110	Main Nozzle Positioning Units
20	S/R	Intake Baffle
21	S/R	Support
22	4616.109	Main Injector
23	4616.116	Tilt Switch
24	S/R	Butterfly Clip
25	S/R	Steel Pipe
26	S/R	Flame Screen Base
27	S/R	Observation Hole Baffle
28	S/R	Main Fire Pipe
29	4616.115	Thermocouple
30	4616.104	Electrode
31	4616.102	Die-Casting Duct
32	4616.117	Vavle
33	S/R	Small Mesh Base
34	S/R	Vavle Support
35	4616.101	Control Panel
36	4616.118	Vavle Nut
37	4616.108	Knob
38	4616.107	Ignitor
39	S/R	Gas Hose
40	4616.106	Hold Hoop

S/R = Parts available on special request only

www.serviscentrum.cz
info@serviscentrum.cz
+420 607 607 077