


22 GENERATOR



REF.	PART NUMBER	PART NAME	CODE NO.	QTY	REMARKS	INTERCHANGE
1	36C-20007-08	STATOR CP	-	1		RGN15250341002
2	36C-20101-08	ROTOR CP	-	1		RGN15200454002
3	36C-20206-08	AVR CP	-	1		
4	36A-20300-08	BRUSH CP	-	1		
5	36C-22000-08	GEN BRACKET 1	-	1		
6	36C-22100-08	GEN BRACKET N	-	1		
7	36C-22200-08	GEN BRACKET 2	-	1		
8	36C-23000-08	BRACKET COVER	-	1		
9	36C-25000-08	BUSHING	-	1		
10	36B-21000-08	STATOR BOLT	-	4		
11	36A-80005-08	FLANGE BOLT	-	4		
12	36A-80001-08	FLANGE BOLT	-	2		
13	36A-80100-08	SCREW & WASHER AY	-	1		
14	36A-80002-08	FLANGE BOLT	-	4		
15	36A-25001-08	DIODE CP	-	1		
16	36A-80101-08	SCREW & WASHER AY	-	1		
17	36C-25002-08	TUBE	-	1		
18	36A-25003-08	GROMMET	-	1		
19	36A-70000-08	CONNECTOR(6P)	-	1		
20	36A-70004-08	CONNECTOR(4P)	-	1		
21	36A-70002-08	CONNECTOR(2P)	-	1		
22	36A-70101-08	RETAINER(2P)	-	3		
23	36A-70100-08	RETAINER(3P)	-	2		
24	36A-71013-08	WIRE(GREEN)	-	1		
25	36A-71001-08	WIRE(WHITE)	-	1		
26	36A-80200-08	SCREW	-	4		
27	36A-70005-08	CONNECTOR AY	-	1		
28	36C-21100-08	ROTOR BOLT	-	1		
29	36C-25004-08	SPONGE(FILTER)	-	1		