


22 GENERATOR



REF.	PART NUMBER	PART NAME	CODE NO.	QTY	REMARKS	INTERCHANGE
210	35G-51018-01	STATOR CP	-	1		
220	35G-51003-01	ROTOR CP	-	1		
222	354-58204-08	BALL BEARING	-	1		
224	355-58009-08	THROUGH BOLT	-	1		
240	354-54116-08	FRONT BRACKET	-	1		
244	359-59935-08	BOLT & WASHER AY	-	4		
250	31D-51023-01	STATOR COVER	-	1		
260	31H-53001-01	REAR BRACKET	-	1		
264	31D-51025-01	COVER BOLT	-	4		
266	003-20080-00	SPRING WASHER	-	4	8. 2DX15. 4DX2T	
280	354-54513-08	BRUSH COVER	-	1		
282	31G-74001-01	BRUSH HOLDER CP	-	1		31H-54002-01
284	30A-71202-03	SCREW & WASHER AY	-	2		
285	31G-62001-01	SCREW & WASHER AY	-	2		013-10500-30
440	35G-53001-01	EARTH WIRE CP	-	1		
492	353-57506-18	BUSHING	-	1		
680	392-49986-08	SCREW	-	1	M4X6L	